MT-1402 Operating Manual

1). The functional specification

Pattern: DAB, FM, bluetooth, AUX_IN, MP3, USB, SD playback).

Output 5 v / 1A for charge phone

Alarm clock: ALARM1, ALARM2 dual.

LCD: lattice screen black white

The power adapter, 100-240 - v AC INPUT DC_OUTPUT 9 v / 2.5 A

Output power: 5 w * 2

2). Buttons Menu On Panel

1. POWER --- standby button, standby and switch
2. MENU ---MENU information button
3. MODE --- MODE switch button
4. Alarm --- clock key
5. Presets --- Station save button
6. ⏮ --- Previous song/back/ up selection button
7. ⏯ --- pause/play
8. ⏭ --- next song/fast forward/down to select button
9. **+** --- volume increasing
10. **-** --- volume reduction
11. S E L E C T ——SELECT button
12. S C A N ——radio automatically SCAN button

3). POWER-ON instructions

1. Plug the POWER transformer into a DC 9 v interface, then machine will start. Press the red button POWER, machine will be into working state, press the POWER button again, machine is standby.

4). DAB MODE Operation

1. Press Mode into the DAB Mode after Machine starts. press the SCAN button to Full SCAN, then the machine is scanning DAB station, it needs a relatively long time, and will appear the number of stations in the process of scanning. After SCANNING, it will automatically save the received and display the received DAB stations.

2. The first received station will automatically play.

3. Press ⏮ and ⏭ can choose favorite stations freely.

4. Press+, - to control volume.

5. If you want to store the playing station, long press Presents button to activate storage function, display will show Empty1 to 16 right now, then press ⏮ and ⏭ to choose the storage place，press again ＳＥＬＥＣＴ button to memorize stations，and display will come to a reminder Preset x Stored ，the max capacity is 16 stations.

If you want to play storage station, you could shortly press Presents button to activate storage function, and then press
⏮ and ⏭ to choose place of prestore stations，press ＳＥＬＥＣＴ button to confirm，then radio will be playback.

7. Time and date in the radio will automatically synchronize station in DAB Mode.

8. In the stare of DAB mode, press ＭENU button will show DLS、Station name、time/date and in DAB Mode。

9. In the state of DAB mode, press Menu button to choose Manual Tune and press again SELECT button into manaul channel selection function，press ⏮ and ⏭ , choose the needed frequency（5A-13F），after receiving station, press SELECT button to confirm the channel，then press again ⏮ and ⏭ choose the program in frequency， press SELECT to play after confirmation.

5). FM MODE Operation

1. Press Mode button turn to FM mode， display will show FM frequency(87.5MHz.-108MHz).

2. Now you can short press ⏮ and ⏭ button to adjust needed frequency，the range of frequency adjustment is 0.05MHZ。

3. It will automatically reach station once press SCAN button，when come to a strong signal，it will automatically stop to play it.

5.If you want to store the playing station, long press button to activate storage function, now you will see Empty 1 to 16, then press ⏮ and ⏭ to choose the storage place，and press ＳＥＬＥＣＴ button to memorize station，display will show related reminder Preset x Stored ，which has capacity of 16 stations；

If need to callout storage stations, you may press Presents button to activate this callout storage function, then press ⏮ and ⏭ to choose the place of preset stations，press ＳＥＬＥＣＴ button to confirm，preset station will be playback 。

5. Press the MENU button will displays the RDS FM mode information, audio type, radio frequency, time and date, signal quality, program text, program type.

6.Press +, - to adjust volume.

6). BT MODE OPERATION

1.Press Mode key turn to bluetooth Mode, the machine will have a "du" voice prompt to enter a state of the bluetooth pairing, display

shows Pairirng；

a:Open the bluetooth in mobile phone, search the matching name according to the connection;After the successful connection, display shows Connected OK。

2. Press ⏯ button is pause，and playback.
3. Press⏮ and⏭ , you can choose previous song and next song.

4. Press+, -to adjust volume.

7). AUX-IN MODE OPERATION

1. Press Mode key turn to AUX - IN pattern, put the input audio line at the top of the AUX IN jack (3.5 mm) , then it will play outside music.

2. Press+, -to adjust volume.

8). USB MODE OPERATION

1. Press Mode key turn to MP3 Mode, insert the USB device at the top of the USB port, the machine automatically read audio files on the USB device and automatically play music.

2. Press ⏯ button is pause，and playback.
3. Press ⏮ and,⏭ you can choose previous song and next song.
4. Press+, -to adjust volume.

9). SD MODE OPERATION

1. Press Mode key turn to SD model, insert SD card into the top of the SD socket, the machine automatically read SD card audio files and automatically play music.

2. Press ⏯ button is pause and playback..

3. Press ⏮ and ⏭ , you can choose previous song and next song.

4. Press+, -to adjust volume.

10). SYSTEM OPERATION

1.Time and date setting:In state of standby, press Menu into Clock, press again Select into time and date setting. Preset hour, press ⏮ and ⏭ to choose time, long press these two buttons you can promptly choose time. After setting time, press SELECT to confirm into minute setting, minute setting is same as hour setting；After time setting. Press SELECT to confirm finishing into date setting. press ⏮ and ⏭ to choose month. Long press these two buttons you can promptly choose year, after that, press SELECT to enter month and date setting, month or date setting are same as month.

2. ALARM Function：Dual ALARM, One hour ALARM time，nine hour SNOOZE time.

you can set the ALARM In standby and boot. ALARM can awaken the DAB, FM, BEEP Tone. There will be flashing on the display when come to ALARM clock time

3. Setting ALARM in Standby mode，after ALARM is activated，you can press Alarm into Snooze, press Standby to close Alarm

5. ALARM INSTRUCTION:

a, Alarm DAB, after awaken DAB, it will play DAB program, if without DAB station, radio will BEEP.

b. ALARM FM，It will play FM station after awaken FM.

6. ALARM SETTING（ALARM1 as example），press Alarm into Alarm1 setting，display will show Statns:Press OFF ⏮ and ⏭ to choose ON button to activate ALARM1 function into time setting，press ⏮ and ⏭ to choose time，long press these two buttons can promptly choose time，after hour setting, press ＳＥＬＥＣＴ button into minute setting，minute setting is same as hour setting，after time setting, press ⏮ and⏭ to choose alarm style，BEEP,DAB,FM,three modes are optional，choose one of them and press ＳＥＬＥＣＴ button；now time setting is over.

ALARM2 setting is same as ALARM1，after ALARM1 ring and come to ALARM2，ALARM1 will be automatically closed.

7.ALARM VOLLUME：Alarm volume is from low to high.

8. Press ALARM button to snooze function after alarm ring, snooze time is nine minutes. After 9minutes snooze, you could press ALARM button to continue snooze again if needed. If dual ALARM are into Snooze function，system will only wake the last ALARM for snooze. There will be two Z reminder sign when it is Snooze state.

9. Sleep (Sleep) : in the boot state, press the ALARM button to enter Sleep function setting, example: press ALARM again choose 90 mins (continuous press ALARM can also SELECT 15 mins, 30 mins, 45 mins, 60 mins, choose OFF OFF Sleep) and then press the SELECT key to confirm to open the Sleep function;The standby time will be displayed on the right LCD; When time is coming, machine will automatically enter the standby time.

10). With USB charging line inserted into the USB interface for charging mobile phone.